



Sulky Cavalettie Sport®


Assembly instruction




Ax1




Bx1




Cx1




Dx1




Ex1




Fx1




Gx2



Hx2




Ix1



Jx1



Kx2




Lx1




Mx1




Nx1




Ox2




M20
Px2




M20
Qx2




M10
Rx2




M10
Sx2




Tx2




11-13




14-17




30



#2.5



#4



#5

